

## MAINTENANCE

Wipe with a clean, dry cloth. For tips on maintaining your SureFire illumination tool, visit [www.surefire.com/faqs-maintenance](http://www.surefire.com/faqs-maintenance).

## ACCESSORIES

SureFire makes a full line of accessories for most of its illumination tools. For a complete listing, visit [www.surefire.com/parts-accessories](http://www.surefire.com/parts-accessories).

## THE SUREFIRE NO-HASSLE GUARANTEE

We'll do what it takes to keep your SureFire gear running smoothly. SureFire warrants that if you — our customer — purchase one of our products, and we determine that it is defective in material and/or workmanship during your lifetime, we will repair or replace it — no hassle!

Our warranty does not cover consumables or normal wear-and-tear — things like batteries draining, headbands and headpads wearing out, ink cartridges running out, and switches wearing out — or damage resulting from abuse, alterations, unauthorized repairs, or use contrary to SureFire's user manuals.

Should you need a replacement product, SureFire reserves the right to replace an obsolete product with a current production, like model. In the event that any issue with a SureFire product is not covered under this warranty SureFire can arrange to have the product repaired for a reasonable fee.

## STANDARD DISCLAIMER

Except as specified above or prohibited by applicable law: all express or implied conditions and warranties, including, without limitation, any implied warranty or condition of merchantability or fitness for a particular purpose, or accuracy of any informational content, are hereby excluded and disclaimed by SureFire; and in no event will SureFire be liable for any special, direct, indirect, consequential, incidental or punitive damages howsoever arising and regardless of the theory of liability, even if advised of the possibility of such damages. Products, prices, availability, specifications, and offers are subject to change or cancellation at any time without notice.

## WARRANTY CLAIMS

For claims, contact Customer Service at 714-545-9444 to obtain a Return Merchandise Authorization number (RMA#). Then package the unit carefully and send to (no CODs):

SureFire, LLC.  
Repairs Department, RMA# \_\_\_\_\_  
17680 Newhope Street, Suite B  
Fountain Valley, CA 92708

SureFire will pay any reasonable shipping costs to return the unit to you.



Revision A 10-2018  
71-01-1077  
E2DLU-T


18300 MT. BALDY CIRCLE  
FOUNTAIN VALLEY, CA 92708-6122  
[WWW.SUREFIRE.COM](http://WWW.SUREFIRE.COM)

Patents: 6547415, 6222138, RE40125



# SUREFIRE®

## E2D DEFENDER TACTICAL SINGLE-OUTPUT LED FLASHLIGHT



SPECIFICATIONS		E2D DEFENDER TACTICAL
OUTPUT		1,000 lumens
RUNTIME		2.75 hours
PEAK BEAM INTENSITY		10,600 candela
DISTANCE		200 meters
CONSTRUCTION		Aluminum
FINISH		Mil-Spec Hard Anodized
WEIGHT (w/batteries)		4.2 oz (119 g)
LENGTH		5.6 in (14.2 cm)
BEZEL DIAMETER		1.125 in (2.85 cm)
BATTERIES		Two 123A lithium (incl.)
SWITCHING		Click tailcap

All performance claims tested to ANSI/NEMA FL1-2009 Standard.


## USER MANUAL

## E2D DEFENDER TACTICAL

### LOCKOUT TAILCAP (US PAT. RE40125)


Most SureFire illumination tools feature a lockout tailcap, which prevents accidental activation during storage or transport. The tailcap may need to be enabled prior to light operation.

**To enable**, rotate tailcap clockwise until light activates when tailcap pushbutton is pressed.



**To lock out tailcap**, rotate counterclockwise until light will not activate when pushbutton is pressed.

### LIGHT OPERATION



### BATTERY REPLACEMENT

Most SureFire illumination tools ship preloaded with batteries. To load or replace batteries:

1. Unscrew head counterclockwise and remove.
2. Remove old batteries and dispose of properly.



3. Insert two new 123A lithium batteries with positive (+) terminals oriented forward.
4. Replace head by screwing on clockwise.

### ⚠ WARNING

Use of substandard batteries can cause injury or property damage. Visit [www.surefire.com/batterysafety](http://www.surefire.com/batterysafety).

### BATTERY INFORMATION & WARNINGS

For complete battery information and warnings, reference the enclosed BATTERY INFORMATION / WARNING insert in your illumination tool's original packaging or visit [www.surefire.com/batteries](http://www.surefire.com/batteries).

## MAINTENANCE

Wipe with a clean, dry cloth. For tips on maintaining your SureFire illumination tool, visit [www.surefire.com/faqs-maintenance](http://www.surefire.com/faqs-maintenance).

## ACCESSORIES

SureFire makes a full line of accessories for most of its illumination tools. For a complete listing, visit [www.surefire.com/parts-accessories](http://www.surefire.com/parts-accessories).

## THE SUREFIRE NO-HASSLE GUARANTEE

**We'll do what it takes to keep your SureFire gear running smoothly.** SureFire warrants that if you — our customer — purchase one of our products, and we determine that it is defective in material and/or workmanship during your lifetime, we will repair or replace it — no hassle!

Our warranty does not cover consumables or normal wear-and-tear — things like batteries draining, headbands and headpads wearing out, ink cartridges running out, and switches wearing out — or damage resulting from abuse, alterations, unauthorized repairs, or use contrary to SureFire's user manuals.

Should you need a replacement product, SureFire reserves the right to replace an obsolete product with a current production, like model. In the event that any issue with a SureFire product is not covered under this warranty SureFire can arrange to have the product repaired for a reasonable fee.

## STANDARD DISCLAIMER

Except as specified above or prohibited by applicable law: all express or implied conditions and warranties, including, without limitation, any implied warranty or condition of merchantability or fitness for a particular purpose, or accuracy of any informational content, are hereby excluded and disclaimed by SureFire; and in no event will SureFire be liable for any special, direct, indirect, consequential, incidental or punitive damages howsoever arising and regardless of the theory of liability, even if advised of the possibility of such damages. Products, prices, availability, specifications, and offers are subject to change or cancellation at any time without notice.

## WARRANTY CLAIMS

For claims, contact Customer Service at 714-545-9444 to obtain a Return Merchandise Authorization number (RMA#). Then package the unit carefully and send to (no CODs):

SureFire, LLC.  
Repairs Department, RMA# \_\_\_\_\_  
17680 Newhope Street, Suite B  
Fountain Valley, CA 92708

SureFire will pay any reasonable shipping costs to return the unit to you.



Revision A 10-2018  
71-01-1078  
E2DLU-A


18300 MT. BALDY CIRCLE  
FOUNTAIN VALLEY, CA 92708-6122  
[WWW.SUREFIRE.COM](http://WWW.SUREFIRE.COM)

Patents: 6547415, 6222138, RE40125



# SUREFIRE®

## E2D DEFENDER® DUAL-OUTPUT LED FLASHLIGHT



SPECIFICATIONS		E2D DEFENDER	
OUTPUT		High: 1,000	Low: 5 lumens
RUNTIME		High: 2.75	Low: 63 hours
PEAK BEAM INTENSITY		10,600 candela	
DISTANCE		200 meters	
CONSTRUCTION		Aluminum	
FINISH		Mil-Spec Hard Anodized	
WEIGHT (w/batteries)		4.2 oz (119 g)	
LENGTH		5.6 in (14.2 cm)	
BEZEL DIAMETER		1.125 in (2.85 cm)	
BATTERIES		Two 123A lithium (incl.)	
SWITCHING		Click tailcap	

All performance claims tested to ANSI/NEMA FL1-2009 Standard.


## USER MANUAL

## E2D DEFENDER<sup>®</sup>

### LOCKOUT TAILCAP (US PAT. RE40125)

Most SureFire illumination tools feature a lockout tailcap, which prevents accidental activation during storage or transport. The tailcap may need to be enabled prior to light operation.


**To enable**, rotate tailcap clockwise until light activates when tailcap pushbutton is pressed.



**To lock out tailcap**, rotate counterclockwise until light will not activate when pushbutton is pressed.

### LIGHT OPERATION

Press or click tailcap switch once for high output. Return to off and press or click on again, within two seconds, for low output.



### BATTERY REPLACEMENT

Most SureFire illumination tools ship preloaded with batteries. To load or replace batteries:

1. Unscrew head counterclockwise and remove.
2. Remove old batteries and dispose of properly.



3. Insert two new 123A lithium batteries with positive (+) terminals oriented forward.
4. Replace head by screwing on clockwise.

### **⚠ WARNING**

Use of substandard batteries can cause injury or property damage. Visit [www.surefire.com/batterysafety](http://www.surefire.com/batterysafety).

### BATTERY INFORMATION & WARNINGS

For complete battery information and warnings, reference the enclosed BATTERY INFORMATION / WARNING insert in your illumination tool's original packaging or visit [www.surefire.com/batteries](http://www.surefire.com/batteries).